


		5		\forall	4	4	1		3	
Y(GRAINS)			FLOW RATE (gpm)						WEIGHT (Ib	
6 Ibs/	/ft³	MAX SYSTEM	MIN	CRITICAL	SERVICE	15psi ∆P	25psi ∆P	BACKWASH	SHIPPING	OPE
60,00	00	180,000	2.1	8.5	13.0	19.0	26.0	5.3	500	1

1



DRAWING IS FOR REFERENCE ONLY. PIPING AND INSTRUMENTATION SHOWN ARE NOT INCLUDED IN THE SCOPE. RECOMMEND INSTALLING HORIZONTAL FLEX CONNECTORS ON BOTH INLET AND **OUTLET FOR FRP TANK EXPANSION.** 4. RECOMMEND INSTALLING VACUUM BREAKER(S) ON ALL INLET FRP TANK **CONNECTIONS.** 5. PROVIDE AN AIR GAP ON DRAIN LINE OF AT LEAST 4 TIMES THE DIAMETER OF THE PIPE OR FOLLOW LOCAL PLUMBING CODES. 6. OUTLET OF SOFTENER "A" GOES TO INLET OF MAV "A" & OUTLET OF SOFTENER "B" GOES TO INLET OF MAV "B"

